


This product contains a light source in energy efficiency class G /
Dette produkt indeholder en lyskilde i energieffektivitetsklasse G

1




Remove the USB-C dust plug and put it away to prevent it from being lost.

2


Charging: the light is red.

Battery fully charged: the light is green.





Use the white charging cable to charge and input the power adapter 5V/2A.

3



After charging, install the USB-C dust plug.

4



Long press to adjust brightness.

Click the touch button to control the switch, then press and hold to adjust the brightness.